

Thank you for the opportunity to work with you on this project! Below are the steps to get your Secure-Rite Building up and running smoothly!

NOTE:

- The connections must be made by a qualified electrician
- The panels are rated for 100 Amps 240 Volts so the wire size should be 3 conductor #1 aluminum if the supply is 100 amps.



Step 1

There is a junction box on the exterior. Remove the front plate. Drill a hole in the bottom that is wide enough to feed your wires through



Step 2

Feed cable through bottom and plug into junction box. It is also important to support the cable within 1ft of the junction box.



Step 3

Terminate the cables onto the lugs in the panel. Test to ensure the electrical is working. Reattach the cap, and enjoy your Secure-Rite Building!