

### TELECOM BOX HOOK UP (Standard)

Below are the steps for hooking up telecommunications to your Secure-Rite building.



#### Step 1

There is a telecommunications box on the exterior of your unit. Open the front cover with a blade screw driver

#### Identify Cables:

Cable 1 – Telecom  
Cable 2 - Data



#### Step 2

Punch a hole as shown, feed conduit through bottom, and plug into telecom box.



#### Step 3

Connect cables to corresponding ports. Reattach the cap. Enjoy your Secure-Rite Building!

